

Grill Guard Installation Guide

4044R, 4052R & 4066R

Thank you for your purchase! We want you to be completely satisfied with our products. If you have any questions or concerns, please reach out via the contact information above and we will do all that we can to assure your experience with us is a positive one.



Qty: 4 - M12 x
25mm Flanged
Head Screw



Qty: 4 - M12
Nylon Lock Nut



Qty: 4 - M10 x
25mm Carriage
Bolt



Qty: 4 - M10
Nylon Lock Nut

Below is the process for installing the 511 grill guard on your tractor.

- 1) Although not always necessary for this installation, it is helpful to remove the loader from the tractor.
- 2) Open the hood.
- 3) Remove each of the side panels:
 - a. Fold out and twist the turn fasteners and pull the panels outward until clear of the turn fasteners (Figures 1&2).
 - b. Slide the side panels forward out of the grommets in the console (Figure 3).
- 4) Unplug the headlight harness from the main harness (Figure 4).
- 5) Release the 2 over center latches on each side of the front grill by pulling them downward (Figure 5).
- 6) Remove the grill and headlight assembly by lifting upward making more room for the grill guard installation.
- 7) Place the upper 511 grill guard into the factory brush guard frame from the front side until the four flanges with the oval shaped holes line up with the 4 square holes in the sides of the factory brush guard (Figure 6).
- 8) Install the 4 carriage bolts from the outside through the factory brush guard's frame and the flange of the 511 guard followed by the lock nuts. Tighten the nuts.
- 9) With the pointed portion up and facing forward, place the lower guard on the back side of factory guard's cross bar (Figures 6&7).
- 10) Install the 4 M12 screws through lower guard and back of the crossbar on the factory guard followed by the washers and lock nuts. Tighten each of the nuts.
- 11) Reinstall the grill and headlight assembly by lining up the slots on the bottom with the grill assembly.
- 12) Secure the 2 over center latches on each side of the front of the grill by rotating them upward. Plug the headlight harness into the main harness.
- 13) Slide each of the side panels rearward into the grommets in the console.
- 14) Align the slots and place the side panels over turn fasteners and twist and fold the fasteners inward to secure the panels on each side.
- 15) Close the hood.
- 16) Reinstall the loader if previously removed.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7



Completed installation