



5Eleven DesignZ, LLC

Email: sales@5elevendesignz.com

Phone: 734-719-0311

Grill Guard Installation Guide

5045E, 5055E, 5060E, 5065E & 5075E with the H240, 500M, 512, or 520M loader

Thank you for your purchase! We want you to be completely satisfied with our products. If you have any questions or concerns, please reach out via the contact information above and we will do all that we can to assure your experience with us is a positive one.

Below is the process for installing the 511 grill guard on your tractor.

- 1) Remove the 4 front carriage bolts from each side of the upper and lower crossbars. Retain the hardware.
- 2) Place the 511 grill guard onto the factory brush guard frame from the front side.
- 3) Align the holes on the flanges of the 511 guard with the holes in the sides of the factory guard.
- 4) Reinstall the four carriage bolts that were removed during step 1 on each side and install the washers and nuts. Do not tighten the nuts at this time.
- 5) Position the 511 guard to your liking and clamp in place. Spring clamps work well to hold the guard in place. It is recommended to leave a small gap between the 511 guard and the crossbars of the factory guard.
- 6) Tighten each of the four carriage bolts.
- 7) Installation is now complete.



Completed installation